



FINISH APPLICATION #Z127 CORK RUBBER FLOORING

Though not required, Zandur recommends the application of Johnson Diversey Carefree Matte Floor Finish to increase ease of maintenance and provide additional protection to flooring surface. This product, applied by qualified maintenance personnel, is used commonly on many types of resilient flooring. It can be applied in just a few hours and can be walked on immediately when dry.

All Zandur Cleaning and Finishing Products are available directly from Zandur. Contact your local sales group for pricing and information.

I. PRE-APPLICATION MAINTENANCE

- A. Prior to applying finish onto floor, clean floor according to Zandur maintenance instructions (document #Z123). For first time applications, ensure post installation maintenance has been properly performed.
- B. Do not proceed with finish application unless floor is clean and all floor is closed to foot traffic other than maintenance personnel.

II. APPLICATION OF FLOOR FINISH

- A. Apply Johnson Diversey Carefree Matte according to manufacturers instruction. Apply a minimum of 4 coats using a clean cotton blend mop. When a coat is applied properly, the floor should only look wet. During application, finish should not be puddled or appear white. If that occurs, too much finish is being applied. Numerous THIN coats will provide the best results in terms of scuff resistance and durability.
- B. Re-application of floor finish should occur when finish begins to show signs of wear. The re-coating process can be performed overnight and immediately ready for traffic when dry.
- C. Existing finish does not need to be stripped prior to re-application of finish. Stripping is only necessary when finish coats have built up.
- D. Proper regular maintenance will significantly increase the length of time before the floor needs to be coated again.

III. STRIPPING

- A. Stripping is necessary only when floor finish becomes built up after repeated application. It is not required prior to each application of floor finish. Many users never strip their floor. At most this process is done once per year for very high traffic installations.
- B. Prior to stripping the entire floor, perform the following procedure in a test area to verify that flooring material is not discolored or damaged in any way.
- C. Sweep and vacuum the floor. Following the manufacturer's instructions, apply Johnson Diversey Linosafe Stripper to the floor. Strip only a small section at a time.
- D. Allow stripper to act on the floor for 5 minutes and use a buffer or auto scrubber with a green or blue pad to scrub the floor. **DO NOT USE A BLACK OR BROWN PAD.**
- E. Remove residue with a wet vac and rinse floor with water using a clean mop. Allow the floor to dry for 2-4 hours.

Zandur Cork Rubber Flooring

Finish Application #Z127

- F. Apply a minimum of 4 coats of Johnson Diversey Carefree Matte according to manufacturer's instruction. Refer to section II above.

IV. Routine Maintenance

- A. Follow guidelines set forth in Zandur document #Z123. This can be obtained from your local distributor, or at www.zandur.com.

V. Reference Documents:

- Z123 Cork Rubber Flooring Maintenance Guide
- Z130 Product Suitability and Benefits
- Z125 Carefree Matte Specification Sheet
- Z126 Carefree Matte MSDS
- Z131 Linosafe Stripper MSDS

For information on Johnsons Diversey products, refer to www.jwp.com

For a complete listing of all Zandur product documentation, please refer to www.zandurdocs.com