



INSTALLATION INSTRUCTIONS WALL AND CEILING APPLICATIONS

- Cork Rubber Flooring
- Composition Cork Rolls
- Colored Cork/Linoleum Rolls
- Cork Floor Tile
- Cork Wall Tile

Acclimate material (reverse roll composition cork and colored cork) and adhesive for a 72 hour period in room where it is to be installed.

1. Surface requirements:

Material must be mounted to walls or ceilings that are clean, dry and free of dust, oils, wax or any other products that might interfere with the adhesion of the cork. Clean unfinished wood and drywall are suitable surfaces. The surface must be smooth and level to assure the final installation will meet visual standards. For painted or other surfaces finished in anyway, the surface must be abraded to permit bonding of the adhesive. In all cases, perform a bond test first to ensure adhesion. A bond is sufficient if after 24 hours, the material cannot be removed by hand or tool in one piece. Properly bonded material will come off in small pieces. Zandur cannot be held responsible for adhesion problems. When material is applied to ceilings, we recommend a substrate that is rigid and made of a fire retardant material.

2. Recommended Systems:

- *Cork Rubber Floor Tile*: This material can be applied on walls or ceilings using contact adhesive or Zandur #10 adhesive.
 - *Cork Wall Tile*: This material can be applied on walls or ceilings using contact adhesive or Zandur #10 Adhesive.
 - *Composition Cork*: Apply to walls using Zandur #10 adhesive. We do not recommend the use of composition (bulletin board) cork on ceilings.
 - *Colored Cork Linoleum*: Apply to walls using Zandur #10 adhesive. We do not recommend the use of this product on ceilings.
 - *Cork Floor Tile*: This material can be applied on walls or ceilings using solvent based contact adhesive.
- * If solvent based contact cement is used, Zandur recommends, Formica 100+, DAP or any other equal solvent based product.

A. Installation With Zandur #10 Adhesive

- Using a 3/32" X 3/32" X 3/32" v-notch trowel, spread adhesive on wall surface. The working time will be approximately 20 minutes. It is recommended to apply the cork to the wall after an open time of 10 minutes. Adhesive transfer should be visible on at least 98% of the tile. This must be verified frequently during installation.

Zandur Installation Instructions for Vertical Applications

- At the time of installation, the material will be adjustable on the wall. Fit material into place in 5 minutes.
- When installing *roll material*, after it is properly positioned, using headless brads, secure the material into place along the upper edge of the material. The sheets should be installed in a vertical manner. Cover seams of sheets with molding if desired.
- When installing tiles, install from the ground up to help prevent tiles from sliding. Use of blue masking tape may be required to hold tiles in place prior to adhesive curing.

B. Installation With Contact Adhesive

- Brush or roll adhesive onto both the wall or ceiling and the back of cork material. Follow manufacturers recommendations for application, open time and working time recommendations.
 - Once adhesive (on both tile and substrate) are dry, the tile can be applied to the wall.
 - Cork will not be adjustable once set into place.
 - Secure tile first with a rubber mallet, then use a hand roller to assure proper transfer across the tile.
3. Hand roll the material to assure proper adhesive transfer. This needs to be done in two directions, within 30 minutes of the adhesive and material application.
 4. Adhesive will gain full strength after 72 hours.

Please call Zandur if you have any questions about installation.